



E45BT / E55BT



E45BT / E55BT

Quick Start Guide

Guide de démarrage

Příručka rychlého startu



What's in the box

Obsah krabice


E45BT / E55BT x 1



x1

Charging cable x 1


Nabíjecí kabel



x1

Detachable audio cable x 1


Odpojitelný audio kabel



x1

Warranty card, QSG, Warning card

**Záruční list, Příručka
rychlého startu,
Varování**



x1

E45BT / E55BT

Quick Start Guide
Guide de démarrage rapide

2 Overview - Buttons & LEDs

a. Buttons & LEDs

Přehled - tlačítka a LED indikátory



b. Connections

Připojení



E45BT / E55BT

Quick Start Guide
Guide de démarrage rapide

3 Bluetooth Connection

Připojení Bluetooth

a. To turn on the headphone

a. Pro zapnutí sluchátek



ON (posunovací tlačítko)



b. For the first time connection the headphone will enter pair mode automatically 5 secs after power on

b. Při prvním připojení vstoupí sluchátka do párovacího modu automaticky 5s po zapnutí

c. Connect via devices


c. Připojte pomocí zařízení

d. Press bluetooth button to pair and connect with the device.

d. Stiskněte tlačítko Bluetooth k párování a připojení k zařízení

1) Bluetooth paring for 1st device

1) Bluetooth párování pro první zařízení



E45BT / E55BT

Quick Start Guide

Guide de démarrage rapide

2) Bluetooth paring for 2nd device

2) Bluetooth párování pro druhé zařízení



3) Go back to the bluetooth device list on the 1st device and click connect

3) Jděte zpět do seznamu Bluetooth zařízení na prvním zařízení a klikněte na připojit



E45BT / E55BT

Quick Start Guide Guide de démarrage rapide

4 Music play

Přehrávání hudby

1) To turn on Bluetooth to pair

1) Zapnout Bluetooth k párování



ON

Zapnuto



3.0s



OFF


Vypnuto



3.0s


2) To pair Bluetooth with the device

2) Spárovat Bluetooth se zařízením



Choose "JBL E45BT" to connect

Pro připojení vyberte "JBL E45BT"



Choose "JBL E55BT" to connect

Pro připojení vyberte "JBL E55BT"



E45BT / E55BT

Quick Start Guide

Guide de démarrage rapide

3) Music control

Ovládání hudby



Stiskněte - Přehrát nebo Pauza



Play or Pause

Press



Next track

Press x2



Previous track

Press x3

Stiskněte 2x - Další skladba

Stiskněte 3x - Předchozí skladba


E45BT / E55BT

Quick Start Guide Guide de démarrage rapide

5

Phone call

Telefonní hovor



Hang up current call and
switch to second call



Switch calls

Long Press

Stiskněte - Zavěste aktuální hovor a přepněte na
druhý hovor
Dlouze stiskněte - přechod mezi hovory

6

Passive listening mode

- 1) Use the headphone with wire
- 2) 2nd device will be the main source of music and movie.
- 3) If you want to change the 1st device to be the main source, stop the music/movie on 2nd device, start the music/movie on the 1st device.
- 4) If there is phone call from either devices, phone call will take the 1st priority
- 5) There are maximum 2 devices can be connected at the same time.

Mód pasivního poslechu

- 1) Použijte kabelové připojení sluchátek
- 2) Druhé zařízení bude hlavním zdrojem hudby
- 3) Pokud chcete aby bylo první zařízení hlavním zdrojem, zastavte hudbu na druhém zařízení a zapněte hudbu na prvním zařízení
- 4) Telefonní hovor na kterémkoliv zařízení má vždy hlavní prioritu
- 5) Najednou mohou být připojena maximálně dvě zařízení

E45BT / E55BT

Quick Start Guide
Guide de démarrage rapide



LED behaviour

LED indikátory



Device mode	Power/ BT LED			Charging LED	
	White	Blue	Flash	Red	Flash
Power on + No BT Connected	YES	NO	Solid On	NO	N/A
Power on + BT Pairing	NO	YES	P5	NO	N/A
Power on + BT Connected	NO	YES	Solid On	NO	N/A
Lower battery + No BT Connected	NO	NO	N/A	YES	P2
Lower battery + BT Pairing	NO	NO	N/A	YES	P2
Lower battery + BT Connected	NO	NO	N/A	YES	P2
Charging Complete	NO	NO	N/A	NO	N/A
Charging in Progress	NO	NO	N/A	YES	Solid On
FW Version LED display*	NO	NO	N/A	YES	P3

E45BT / E55BT

Quick Start Guide

Guide de démarrage rapide

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

E45BT / E55BT

Quick Start Guide

Guide de démarrage rapide

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

E45BT / E55BT

Quick Start Guide

Guide de démarrage rapide

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

E45BT / E55BT

Quick Start Guide

Guide de démarrage rapide

Торговая марка: JBL

Назначение товара: Пользовательские наушники

Изготовитель: Харман Интернешнл Индастриз Инкорпорейтед, США, 06901 Коннектикут, г.Стэмфорд, Атлантик Стрит 400, офис 1500

Страна происхождения: Китай

Импортер в Россию: ООО "ХАРМАН РУС СиАйЭс", РОССИЯ, 127018, г.МОСКВА, УЛ. ДВИНЦЕВ, Д.12, КОРПУС 1

Гарантийный период: 1 год

Информация о сервисных центрах: www.harman.com/ru тел. +7-800-700-0467

Срок службы: 2 года

Товар не подлежит обязательной сертификации

Дата производства: Дата изготовления устройства определяется по двум буквенным обозначениям из второй группы символов серийного номера изделия, следующих после разделительного знака «-». Кодировка соответствует порядку букв латинского алфавита, начиная с января 2010 года: 000000-MY00000000, где «М» - месяц производства (А - январь, В - февраль, С - март и т.д.) и «Y» - год производства (А - 2010, В - 2011, С - 2012 и т.д.).

Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário"

Este produto está homologado pela ANATEL, de acordo com os procedimentos regulamentados pela Resolução 242/2000, e atende aos requisitos técnicos aplicados.

Para maiores informações, consulte o site da ANATEL - www.anatel.gov.br



Slovní značka a loga Bluetooth® jsou vlastněné registrované ochranné známky společností Bluetooth SIG, Inc. a jakékoli použití těchto značek společností HARMAN International Industries, Incorporated je pod licencí. Ostatní ochranné známky a obchodní jména jsou jména jejich příslušných vlastníků.



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by HARMAN International Industries, Incorporated is under license. Other trademarks and trade names are those of their respective owners.

RESTRICTED

DESIGN ADAPTATION / IMAGE / FINAL ART

TR & Job No: TR02171
Job Description: TR02171_JBL_E4S8T+E5S8T_QSG_A
Version : 2
Date: 2016-08-05
Other: N/A



Developed by
SARIN/0823

EQUITY COLORS: REPRESENTATION:



IMPORTANT NOTE : THE PRINT/PDF IS FOR LAYOUT AND TEXT ILLUSTRATION ONLY. THE COLOURS INDICATED HERE MAY NOT APPEAR SAME IN THE FINAL PROOF. ALTHOUGH EVERY EFFORT HAS BEEN MADE TO CHECK THE CORRECTION OF LAYOUT AND TEXT. IT IS CLIENT RESPONSIBILITY TO VERIFY BEFORE GIVING THE FINAL APPROVAL.